



NETGEAR ProSAFE M4300 Series 10-GbE Switch Tutorial

by Benjamin Kenawell, Brian Phelan, Kelly D Sherbondy, and Ram Narayanan

Approved for public release; distribution unlimited.

NOTICES

Disclaimers

The findings in this report are not to be construed as an official Department of the Army position unless so designated by other authorized documents.

Citation of manufacturer's or trade names does not constitute an official endorsement or approval of the use thereof.

Destroy this report when it is no longer needed. Do not return it to the originator.



NETGEAR ProSAFE M4300 Series 10-GbE Switch Tutorial

by Benjamin Kenawell
Science and Engineering Apprentice Program (SEAP), Adelphi, MD

Brian Phelan

General Technical Services (GTS), Wall, NJ

Kelly D Sherbondy
Sensors and Electron Devices Directorate, ARL

Ram Narayanan The Pennsylvania State University (PSU), State College, PA

REPORT DOCUMENTATION PAGE				Form Approved OMB No. 0704-0188	
Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing it data needed, and completing and reviewing the collection information. Send comments regarding this burden estimate or any other aspeburden, to Department of Defense, Washington Headquarters Services, Directorate for Information Operations and Reports (0704-0188 Respondents should be aware that notwithstanding any other provision of law, no person shall be subject to any penalty for failing to con OMB control number. PLEASE DO NOT RETURN YOUR FORM TO THE ABOVE ADDRESS.				ct of this collection of information, including suggestions for reducing the 1, 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302.	
1. REPORT DATE (DD-MM-YYYY) 2. REPORT TYPE			3. DATES COVERED (From - To)		
November 2016 Technical Note				07/2016	
				5a. CONTRACT NUMBER	
4. TITLE AND SUBTITLE				Ja. CONTRACT NOMBER	
NETGEAR ProSAFE M4300 Series 10-GbE Switch Tutorial				5b. GRANT NUMBER	
				35. GRANT NOWIDER	
				5c. PROGRAM ELEMENT NUMBER	
6. AUTHOR(S)				5d. PROJECT NUMBER	
Benjamin Kenawell, Brian Phela	an, Kelly D Sherboi	ndv. and Ram Na	ravanan		
	,,	,		5e. TASK NUMBER	
				SE. TASK NOWIDER	
				5f. WORK UNIT NUMBER	
				SI. WORK ONLY NOWBER	
7. PERFORMING ORGANIZATION NAMI	E(S) AND ADDRESS(ES)			8. PERFORMING ORGANIZATION REPORT NUMBER	
US Army Research Laboratory					
ATTN: RDRL-SER-U				ARL-TN-0803	
2800 Powder Mill Road					
Adelphi, MD 20783-1138					
9. SPONSORING/MONITORING AGENC	Y NAME(S) AND ADDRE	SS(ES)		10. SPONSOR/MONITOR'S ACRONYM(S)	
				11. SPONSOR/MONITOR'S REPORT NUMBER(S)	
12. DISTRIBUTION/AVAILABILITY STATE					
Approved for public release; dis	tribution unlimited.				
13. SUPPLEMENTARY NOTES					
15. SUPPLEINENTARY NOTES					
14. ABSTRACT					
		.1		al accordance and a second of the disadecentary in	
				ol over a single network. The disadvantage is	
a steep learning curve, which this technical note helps alleviate by providing instructions to perform the setup of a simple local area network. It also attempts to explain the process along with other options, including port tagging, multiple virtual local					
area networks, and additional switches, which may be useful in reducing latency and improving throughput.					
15. SUBJECT TERMS					
NETGEAR, server, Cognitive R	adar, network switc	h management, l	ocal area netv	vork, virtual local area network	
16. SECURITY CLASSIFICATION OF:		17. LIMITATION	18. NUMBER	BER 19a. NAME OF RESPONSIBLE PERSON	
10. SECORITI CLASSIFICATION OF:		OF	OF	Vally D Charbandy	

Kelly D Sherbondy

19b. TELEPHONE NUMBER (Include area code)

301-394-2533

ABSTRACT

UU

a. REPORT

Unclassified

b. ABSTRACT

Unclassified

c. THIS PAGE

Unclassified

PAGES

20

Contents

List	of Fi	gures	iv				
1.	Introduction						
2.	Startup						
3.	Connecting to the Switch						
4.	Con	necting to the Management Interface	1				
5.	Sav	ing a Configuration	3				
6.	Add	ling/Deleting Users	3				
7.	Set	ting Up a DHCP Virtual Local Area Network (VLAN)	3				
	7.1	Setting Up a New VLAN	4				
	7.2	Add an Interface to the VLAN	4				
	7.3	Untag All Ports	5				
	7.4	Assign Ports to Use VLAN	6				
	7.5	Excluding IP Addresses	7				
	7.6	Setting Up a DHCP Pool	7				
8.	Stat	tic Network	8				
9.	Por	t Aggregation/Link Aggregation Control Protocol	9				
	9.1	Adding LAG to VLAN	9				
	9.2	Adding Ports to LAG	10				
	9.3	Checking the LAG	10				
10.	Sta	cking Switches	11				
11.	. Conclusion						
12.	. References						
Dist	ribut	ion List	13				

List of Figures

Fig. 1	NETGEAR login	2
Fig. 2	Maintenance tab	3
Fig. 3	Setting up a new VLAN	4
Fig. 4	Adding an interface	5
Fig. 5	Untagging all ports	6
Fig. 6	Assigning ports	7
Fig. 7	Excluding IP addresses	7
Fig. 8	DHCP pool configuration	8
Fig. 9	Adding ports to the LAG	10
Fig. 10	LAG settings and ports	11

1. Introduction

The NETGEAR ProSAFE M4300¹ series 10-GbE network switch is a fully managed switch. As such, it has lots of options that may seem complicated at first. Once the user learns the terminology and thought process behind the options, such a switch has a very powerful user interface for fine tuning control of data sent over the network to improve throughput of transfers.

This report provides a short overview and quick tutorial on how to set up some simple but important settings on the switch and lays a foundation for understanding how to proceed in order to achieve maximum bandwidth and throughput of the switch.

2. Startup

To start up the switch, plug it into any 120-V wall outlet. The power light will turn solid yellow and then green after a minute or 2. If the light starts blinking yellow, the switch is not working properly. Once the light turns green, the switch is ready to use.

3. Connecting to the Switch

Next, plug in a connector, RJ45 or SFP+.

Windows will sometimes show an IP address without a gateway. This is not the IP address of the machine. Wait until it has a gateway, the IP address will probably change as well, and then that is the IP address of the machine. Linux does not do this. In either case, the computer should have its final IP address within a minute. In our case, it was in the 192.168.40.0/24 subnet.

4. Connecting to the Management Interface

The out-of-band (OOB) management port on the front of the system is guaranteed to work in case the other ports are not dynamically assigning IP addresses.

For our management interface, the username is "radar" and the password is "ARLpassword12" for all of these methods. Figure 1 shows the NETGEAR login.



Fig. 1 NETGEAR login

The following are various connection options:

- 1) To connect to the NETGEAR ProSAFE switch through a Dynamic Host Configuration Protocol (DHCP) port, open a web browser and navigate to 192.168.40.1.
- 2) To connect to the switch through any of the 16 main ports:
 - a) Open up a web browser and navigate to 192.168.40.1.
 - b) Alternatively, set a network adapter to a static IP of 169.254.100.201.
 - c) Open a web browser and navigate to 169.254.100.100.
- 3) To connect to the NETGEAR ProSAFE switch through the OOB port through a wire Ethernet connection:
 - a) Set the network adapter for a static IPv4 address of 169.254.101.201.
 - b) Open up a web browser and navigate to 169.254.101.100.
- 4) To connect to the NETGEAR ProSAFE switch through the console Ethernet port, one could use a secure shell client, connecting to 192.168.40.1. We do not suggest this method.
- 5) To connect to the NETGEAR ProSAFE switch through the console USB port, one needs drivers on the computer:
 - a) The switch comes with a disk, but disks can also be found online on NETGEAR'S website.²
 - b) The switch also comes with a USB cable, a generic USB Type-A to Mini USB Type-B.

c) The switch also comes with a USB-to-serial connector for console output.

5. Saving a Configuration

The user can change settings and apply them without worry, but unless the user saves the configuration through the Maintenance tab all the changes will be gone once it is powered off (Fig. 2). This is a blessing and a curse. Power cycles every time one makes a change, which can mess up the system. Save the configuration every time a successful change has been made to the configuration.



Fig. 2 Maintenance tab

6. Adding/Deleting Users

Use the following path to added or delete users:

Security→Management Security→Local User→User Management

The default administrator is "admin" without any password. The secondary account (in this case) is radar / ARLpassword12 for a more general audience. There is also a "guest" user without a password with read-only access.

This is where one can add/delete users. One cannot delete the account one has logged in with. We encourage using a password.

Under Security→Management Security→Login Sessions, one can keep track of who is logged in and from where.

7. Setting Up a DHCP Virtual Local Area Network (VLAN)

This process takes some time and understanding to master, because creating a new VLAN does not create the virtual interface to actually use that new VLAN.

It is worth explaining here that a DHCP server creates a local area network that will dynamically assign IP addresses to computers attached to the ports associated with that VLAN. Any devices not DHCP-capable, like software-designed radios, must

be assigned a static IPv4 address on the same subnet as the DHCP pool. In our case, that is 192.168.40.0/24.

7.1 Setting Up a New VLAN

Use the following path to set up a new VLAN:

Switching→VLAN→Basic→VLAN Configuration

The procedures for setting up the new VLAN (Fig. 3) are as follows:

- 1) Type the number of the new VLAN, any unused number between 2 and 4092.
- 2) The name field is optional.
- 3) Then click Add.




Fig. 3 Setting up a new VLAN

7.2 Add an Interface to the VLAN

Use the following path to add an interface to the VLAN:

Routing→VLAN→VLAN Routing Configuration

The procedures for adding an interface to the VLAN (Fig. 4) are as follows:

1) Select the new VLAN ID from the drop-down menu.

- 2) Assign an unused IP address with the last triplet as 1.
 - Remember this when creating the DHCP Pool, as it will use the same address.
- 3) Assign the subnet mask 255.255.255.0.
- 4) Then click Add.

VLAN Routing Configuration

VLAN ID	Port	MAC Address	IP Address	Subnet Mask
400 ~			192.168.1.1	255.255.255.0
1	0/4/1	08:BD:43:71:58:4C	169.254.100.100	255.255.255.0
200	0/4/2	08:BD:43:71:58:4C	192.168.40.1	255.255.255.0

VLAN Routing Configuration

VLAN ID	Port	MAC Address	IP Address	Subnet Mask
~				
1	0/4/1	08:BD:43:71:58:4C	169.254.100.100	255.255.255.0
200	0/4/2	08:BD:43:71:58:4C	192.168.40.1	255.255.255.0
400	0/4/3	08:BD:43:71:58:4C	192.168.1.1	255.255.255.0

Fig. 4 Adding an interface

7.3 Untag All Ports

Use the following path to untag all of the ports:

Switching→VLAN→Advanced→VLAN Membership

The procedures for untagging all of the ports (Fig. 5) are as follows:

- 1) Select the VLAN from the drop-down menu.
- 2) In the Group Operation drop-down menu, select Tag All, then Untag All.
- 3) Then click Apply.

With only one network switch box, do not tag anything. With a second network box, one might have to read up on tagging.³




Fig. 5 Untagging all ports

7.4 Assign Ports to Use VLAN

Use the following path to assign ports to the VLAN:

Switching→VLAN→Advanced→Port PVID Configuration

One needs ports that will connect to the new VLAN and automatically get an IP address in that VLAN, so one must assign ports to use our VLAN (Fig. 6). Since all of the ports are untagged, this step might not strictly be necessary, but it keeps the switch in the loop, so do not leave these steps out.

- 1) Check the boxes on all the ports we want to be part of our new VLAN.
- 2) In the PVID column, type the VLAN ID of our new VLAN.
- 3) Then click Apply.

Note: One can double check VLAN membership here. Under the VLAN Member column, all the VLAN IDs should be there separated by commas. One can also double check that they are all untagged: if they are all comma separated under the Untagged VLANs column and the Tagged VLANs column says "None".




Fig. 6 Assigning ports

7.5 Excluding IP Addresses

Use the following path to exclude IP addresses:

System→Services→DHCP Server Configuration→Excluded Address

Excluding IP addresses is important for the computer as they are assign statically. In order to make sure the DHCP server does not hand out an IP address already being used by one of those computers, one must exclude the one being used (in our case, we must exclude 192.168.40.1).

The procedures for excluding IP addresses (Fig. 7) are as follows:

- 1) In both columns, type the IP address from the VLAN Routing Configuration used to create the VLAN interface by typing a range in here; the user can exclude a greater range of IP addresses. Remember, the range is inclusive.
- 2) Then click Add.




Fig. 7 Excluding IP addresses

7.6 Setting Up a DHCP Pool

Use the following path to set up a DHCP pool:

System→Services→DHCP Server→DHCP Pool Configuration

Under this menu, use these settings:

1) Pool Name: Create

2) Pool Name: Pick any one that is not already found in the drop-down menu.

3) Type of Binding: Dynamic

4) Network Address: A subnet that is not already in use, with the last triplet being 0 (for example, 192.168.1.0).

5) Network Mask: 255.255.255.0

Note: Instead one could type "24" into the Network Prefix Length option, but one cannot do both.

6) Lease Time: Specified Duration

7) Days: 1

Note: This could be any amount of time, but 1 day is fairly standard in industry.

Once the settings have been adjusted, click Apply. Figure 8 shows the DHCP Pool Configuration window.




Fig. 8 DHCP pool configuration

8. Static Network

Configuring a static network is the simplest, most straightforward setup one can achieve on this network switch. However, connecting 2 or more computers to the network in this way makes all the features of the network switch useless.

First, assign a static IPv4 on each computer/device connected. Makes sure all computers/devices share the same subnet (e.g., 192.168.1.0) and change the last triplet for each one. Connect them all to the switch and they will be able to see one other.

To keep certain computers' IP addresses static without having to reassign the same IP in the network adapter every time the user connects, it is possible to configure on the network switch by 1) excluding the IP address from the DHCP pool and 2) configuring the DHCP server to automatically assign the computer's media access control (MAC) address the desired IP address. Note: If the computer has multiple Ethernet ports, one must connect from the same port on the machine to take advantage of this feature or else set it up with the MAC address of each port.

Finally, to connect using an IP address that was dynamically assigned, one can clear all dynamic bindings by navigating to System—Servies—DHCP Bindings Information and then clicking Clear. The DHCP server will automatically reassign all those connections, but avoid the IP of the computer connected statically.

The DHCP server automatically assigns the lowest available IP address. Assigning a static IP higher in the subnet helps avoid IP address conflicts. For example, 192.168.40.200 will almost never be assigned by the DHCP server, so it is a good place to assign a static IP. One will also need to exclude this address from the DHCP server.

9. Port Aggregation/Link Aggregation Control Protocol

The ports on the computer that are connected to the link aggregation group (LAG) on the network switch also need to be set up for port trunking. This report does not go into detail on the process for each computer, because, depending on the operating system, the process varies greatly.

9.1 Adding LAG to VLAN

This is very similar to setting up the DHCP server; however, now the user needs to add the LAG ports to the VLAN, too. If one followed the steps for adding all ports to a DHCP, this may have been done already.

Use the following path to add the LAG ports to the VLAN:

Switching→VLAN→Advanced→Port PVID Configuration

The procedures for adding the LAG ports to the VLAN are as follows:

1) Above the list, click on LAG.

- 2) Check the LAG to change (or all of them).
- 3) Type the ID of the VLAN in the PVID column.
- 4) Then click Apply.

9.2 Adding Ports to LAG

Use the following path to add ports to the LAG:

Switching→LAG→LAG Membership

The procedures for adding ports to the LAG (Fig. 9) are as follows:

- 1) For LAG ID, pick the ID of the desired LAG.
- 2) LAG name can be changed to anything. Name it something that will be a reminder of what it is connected to.
- 3) Select the Hash Mode desired.
- 4) On the Unit 1 box at the bottom, select the ports. They should have a check on them now.
- 5) Then click Apply.




Fig. 9 Adding ports to the LAG

9.3 Checking the LAG

Use the following path to check the LAG:

Switching→LAG→LAG Configuration

The LAG recently changed with the new settings and the ports should be listed (Fig. 10).

Approved for public release; distribution unlimited.




Fig. 10 LAG settings and ports

10. Stacking Switches

Use the following path to stack the switches:

System→Stacking

This looks self-explanatory, but is currently untested.

One can used the following path—Security—Traffic Control—Private Vlan—Private Vlan Type Configuration—when separating 2 or more VLANs on one network switch.

11. Conclusion

A managed network switch, such as the NETGEAR m4300, has a great many ways to set it up. To avoid filling up pages with text, many options are abbreviated, increasing the barrier to entry for a new network manager. In this technical note, we hope the learning curve for this particular managed network switch was greatly decreased for a new user. The other goal was to help the average user to more quickly understand how this particular network switch was set up in order to achieve the desired performance. It should be noted that the setup outlined in this technical note is not the optimal setup for the fastest throughput or lowest latency. Although the network is fast, a more exact knowledge of the computers that will be connected to the network would allow for more precise control of the packets through the network switch, reducing latency for the network as a whole. As previously mentioned, a multiple VLAN setup may also increase throughput. Both of these were beyond the scope of this report, as this is a simple setup guide.

12. References

- ProSAFE intelligent edge managed switches M4300 series data sheet. San Jose (CA): NETGEAR; 2016 [accessed 2016 Jun]. http://www.downloads.netgear.com/files/GDC/datasheet/en/M4300.pdf.
- How to access the command line interface using the console ports of M4100, M4200, M4300, M5300 and M7100 series switches. Article No.: 23561. San Jose (CA): NETGEAR; 2016 Sep 9 [accessed 2016 Jun]. http://kb.netgear.com/app/answers/detail/a_id/23561/~/how-to-access-the-command-line-interface-using-the-console-ports-of-m4100,?cid=wmt_netgear_organic.
- 3. Network Engineering: Why and how are Ethernet VLANs tagged? New York (NY): Stack Overflow; 2015 Jun 2 [accessed 2016 Jun]. http://networkengineering.stackexchange.com/questions/6483/why-and-how-are-ethernet-vlans-tagged.

1 DEFENSE TECH INFO CTR

(PDF) DTIC OCA

2 US ARMY RSRCH LAB

(PDF) IMAL HRA MAIL & RECORDS MGMT RDRL CIO L TECHL LIB

1 GOVT PRNTG OFC

(PDF) A MALHOTRA

1 US ARMY RSRCH LAB

(PDF) RDRL SER U K SHERBONDY INTENTIONALLY LEFT BLANK.